k230OCR character recognition

k230OCR character recognition

k230 and PICO2 communication

- 1. Experimental Prerequisites
- 2. Experimental wiring
- 3. Main code explanation
- 4. Experimental Phenomenon

k230 and PICO2 communication

1. Experimental Prerequisites

This tutorial uses the PICO2 development board, and the corresponding routine path is [14.export\PICO-K230\13_pico_k230_ocr_rec.py].


K230 needs to run the [14.export\CanmvIDE-K230\13.ocr_rec.py] program to start the experiment. It is recommended to download it as an offline program.

Things you need:

Windows computer
PICO2 development board
microUSB cable
K230 visual module (including TF card with image burned in)
type-C cable
connection cable

2. Experimental wiring

k230 vision module	PICO2 Development Board
5V	VCC
GND	GND
TXD(IO9)	RXD(GP9)
RXD(IO10)	TXD(GP8)



3. Main code explanation

```
from machine import UART, Pin
FUNC_ID = 13
uart1 = UART(1, baudrate=115200, tx=Pin(8), rx=Pin(9), bits=8, parity=None,
stop=0)
print("hello yahboom")
def parse_data(data):
    if data[0] == ord('$') and data[len(data)-1] == ord('#'):
        data_list = data[1:len(data)-1].decode('utf-8').split(',')
        data_len = int(data_list[0])
        data_id = int(data_list[1])
        if data_len == len(data) and data_id == FUNC_ID:
            # print(data_list)
            result = data_list[2]
            return result
        elif (data_len != len(data)):
            print("data len error:", data_len, len(data))
        elif(data_id != FUNC_ID):
            print("func id error:", data_id, FUNC_ID)
    else:
        print("pto error", data)
    return ""
last_data = bytearray()
while True:
    if uart1.any() > 0:
        cur_data = uart1.readline()
        # print("rx:", cur_data)
        if ord('\n') in cur_data:
            # data = bytearray(last_data + cur_data.decode('utf-8'), 'utf-8')
```

```
data = last_data + cur_data
    last_data = bytearray()
    result = parse_data(data.rstrip(b'\n'))
    print("ocr_rec:", result)
else:
    last_data = last_data + cur_data
```


The above program is for parsing K230 data. Only when it complies with specific protocols can the corresponding data be parsed.

in

• msg: is the OCR character information.

4. Experimental Phenomenon

1. After connecting the cables, the k230 visual module runs offline. After K230 is connected to Canmv IDE, open the corresponding program, click [Save open script to CanMV board (as main.py)] on the toolbar, and then restart K230.



- 2. Open the Thonny editor, connect the PICO2 mainboard, open the program file and run it. Note: The PICO2 mainboard needs to have the microPython firmware downloaded in advance.
- 3. When the K230 camera image recognizes characters, the terminal will parse and print out the information transmitted by the K230.

in

• msg: is the OCR character information.

As shown in the figure below

[2025-04-30 12:05:30.059]# RECV ASCII> ocr_rec:'HELLO'

[2025-04-30 12:05:30.536]# RECV ASCII> ocr_rec:'HELLO'

[2025-04-30 12:05:31.028]# RECV ASCII> ocr_rec:'HELLO'

[2025-04-30 12:05:31.501]# RECV ASCII>
ocr_rec:'HELLO'

[2025-04-30 12:05:31.976]# RECV ASCII> ocr_rec:'HELLO'

[2025-04-30 12:05:32.481]# RECV ASCII> ocr_rec:'HELLO'